

# OUTERIMPACT

## MICRO RED DOT PATTERN INSTALLATION INSTRUCTIONS

### S&W M&P Shield Plus Optics Ready M.R.D.A. (Micro Red Dot Adapter) Mounting Instructions

- While it is possible to install this mount without the use of a Gun Smith, we recommend using a certified Gun Smith for Installation

**WARNING:** Never remove or install components on a gun without ensuring the gun is not loaded and the chamber is clear.

**Step 1:** Remove existing optics cover plate from the slide.

**Step 2:** Test fit the Red Dot sight to Outerimpact adapter, utilizing adjacent chart. Note: Make sure screws do not stick out beyond bottom of adapter. After test fitting, remove Red Dot sight from adapter

**Step 3:** Secure foundation of sight adapter to slide using T-15 screws in the MNT HDWR bag. Torque to **25 in/lb.**



**Step 4:** Secure top of sight adapter to base with supplied T-10 screws. Torque to **25 in/lb.**



**Step 5:** Attach the optic to the Micro sight using the correct screws, torquing to **12 in/lb.**

**WARNING:** Failure to follow all installation guidelines including recommended torque specifications can lead to property damage and/or bodily harm

Utilize liquid thread locker upon final installation of all threaded fasteners

Note: The adapter has an intentional curve. This curve will flatten out when mounted.