

# OUTERIMPACT™

Required tools:

1 Small Pick

1 11/32 wrenches (if installing the OuterImpact shoulder bolts)

1 1/8 Allen wrench (if installing the OuterImpact shoulder bolts)

- Disassemble the OEM brake lever itself by using the small pick to depress the spring-loaded catch on the retention pin for the brake lever.



- Remove the parking brake mechanism from the OEM brake lever using the same method, the spring catch will need to be depressed twice to clear the lever. The parking brake will be installed on the new OuterImpact lever.



- Install the parking brake to the new OuterImpact lever using either the OEM pin or the OuterImpact shoulder bolt.

- We tape the brake switch down to keep it from being caught when installing the new lever.



- Install the OuterImpact brake lever using either the OEM pin or the OuterImpact shoulder bolt. Be very careful of the brake switch. Remove tape after the lever is installed (if used).

