

OUTERIMPACT





MICRO RED DOT PATTERN INSTALLATION INSTRUCTIONS

WARNING: Failure to follow all installation guidelines including recommended torque specifications can lead to property damage and/or bodily harm

The RED circles indicate locations for 2 alignment pin posts

The BLACK circles indicate locations for mounting screws – Torque to 12in/lbs.

All screws are provided by OuterImpact unless otherwise noted.

Sight Manufacturer	Sight Models	Screws Used
Swampfox Springfield Crimson Trace	Sentinel Wasp CT RAD Micro	M3 x 8  OEM Screws
J-Point Crimson Trace	Micro 1500/1550	M3 x 6  OEM Screws
Shield Riton SOUSA Vector Optics	RMSc/SMSc 3 Tactix MPRD 2.0 X3 Tactix V2 DARC Micro Frenzy S	M3 x 8  M3 x 8 Socket Head Cap Screw
Holosun Vortex Athlon Romeo	407/507K Defender CCW Midas EDC Zero	M3 x 9  M3 x 10
	